

VBC Products Installation Guidelines

Step 1B: Ground Surface Preparation : Aggregate Base

Select the suitable Barrier-Bac Composite product (VBC-350, 31 mil) and ensure the installation surface is relatively smooth. Although Barrier-Bac Composite products are extremely tough, installation is easier and more effective when done over a smooth base. It is optional to have a layer of granular fill under the Barrier-Bac Composite product. The geo-textile fiber side must be facing up.

