

VBC Products Installation Guidelines

Step 2: Unroll and overlap

Barrier-Bac Composite Products should be unrolled to completely cover the pour area. Please place the geo-textile (black color) side facing up. Seams and/or joints can be joined using BB20T Seam Tape. The film should be overlapped six inches side-to-side and end-to-end.

