

VB Products Installation Guidelines

Step 1A: Ground Surface Preparation : Earth Base

Barrier-Bac should be unrolled to completely cover the pour area. Seams and/or joints can be joined using either BB20T Seam Tape or with heat welding. The film should be overlapped six inches side-to-side and end-to-end.

