


STEP 9: Seal Penetrations—Square Penetrations With Block Out

All penetrations must be sealed with the Barrier-Bac Vapor Barrier White Bond Tape. For square posts, please seal penetrations with Block Out Seaming Methods.

1


Cut a piece of Barrier-Bac Vapor Barrier Membrane twice the height and one and one-half the length of the perimeter of the Block Out. Wrap membrane around Block Out and temporarily tape vertical seam.

cut corners approximately half the height of block out



2

Make cuts in each of the four corners approximately half the height of the Block Out. Remove formed Block Out membrane form, flip over and replace on Block Out spreading flaps to horizontal position. Tape all flaps securely with Barrier-Bac White Bond Tape.




STEP 10: Patch Damages

All damages to the film must be sealed prior to pouring. Patch all damaged areas with Barrier-Bac Vapor Barrier products and White Bond Tape.

1

Cut a piece of Barrier-Bac Vapor Barrier in a square large enough so sides of patch extend eight inches from side of puncture.



2

Cover damaged portion with membrane patch and secure all patch seams with Barrier-Bac White Bond Tape.

